



ACTUATORS & MASTER CYLINDERS

Brake actuators convert the energy of compressed air or hydraulic fluid into motion, vital for the safety of your truck or heavy equipment. MGT replacement brake products are designed to meet or exceed original design specifications and provide the same fit, form, and function.

Brake Actuators

Part No.	Description	Machine Model
1029004	ACTUATOR GP-BRAKE	16G, 16H, 16H NA
1298090	ACTUATOR AS-PARKING BRAKE	613G, 950 GC, 950G, 950G II, 950H, 950K, 962G, 962G II, 962H, 962K, IT62G, IT62G II, IT62H
1548041	ACTUATOR AS-PARKING BRAKE	814F, 814F II, 815F, 815F II, 816F, 816F II, 950F, 950F II, 960F, 966F, 966F II, 970F
1548042	ACTUATOR AS-PARKING BRAKE	725, 725C, 730, 730C, 735, 735B, 740, 740B, 824G, 824G II, 824H, 824K, 825G, 825G II, 825H, 825K, 826G, 826G II, 826H, 826K, 966G, 966G II, 966H, 966K, 972G, 972G II, 972H, 972K, 980G, 980G II, 980H
3V7028	ACTUATOR GP-BRAKE	980B
5T0925	ACTUATOR GP-BRAKE	120G, 12G, 130G, 140G, 14G, 14H NA, 160G
6W4280	ACTUATOR GP-BRAKE	824C, 825C, 826C, 980C, 980F, 980F II
8R2488	ACTUATOR GP-BRAKE	966C, 966R
8W8357	ACTUATOR GP-BRAKE	621E, 621F, 621G, 623E, 623F, 623G, 627E, 627F, 627G
8W8358	ACTUATOR GP-BRAKE	621E, 621F, 621G, 623F, 623G, 627E, 627F, 627G
9V8693	ACTUATOR GP-PARKING BRAKE	528, 528B, 530B, 613C, 613C II, 936, 936F, G936
9V8736	ACTUATOR GP-BRAKE	814B, 815B, 816B, 950F, 950F II, 966F, 966F II, 970F

Actuator Repair Kits

Part No.	Description	Machine Model
7K9682	PISTON AS	621, 621B, 621E, 621F, 621G, 623E, 623F, 623G, 627E, 627F, 627G, 824C, 826C, 980B, 980C, 980F
8K8469	PISTON AS	528, 528B, 530B, 613C, 613C II, 814B, 815B, 936, 936F, 950, 950B, 950F, 950F II, 966D, 966F, 966F II, 970F, D35C, D35HP
9L2271	GUIDE-PLUNGER	1140, 1673, 1673B, 1676, 1693, 3176, 3176B, 3176C, 3196, 3208, 3306, 3406, 3406B, 3406C, 3406E, 3456, 980B, C-10, C-12, C-15, C-16, D6C, D9G
5K5935	CYLINDER ASSEM.	814, 966C, 966R
9K0384	CYLINDER AS	528, 528B, 530B, 613C, 613C II, 814B, 815B, 936, 936F, 950, 950B, 950F, 950F II, 966D, 966F, 966F II, 970F, D35C, D35HP, G936
1870424	KIT-REPAIR	14H, 16G, 16H, 16H NA, 518C, 621E, 621F, 621G, 623E, 623F, 623G, 627E, 627F, 627G
2G2287	KIT-DUST BOOT	120G, 12G, 14G, 16G, 621, 621B, 621E, 627E, 772

Part No.	Description	Machine Model
1233426	CYLINDER AS-BRAKE MASTER	416C, 426C, 428C, 436C, 438C
1678161	CYLINDER AS	416D, 420D, 424D, 428D, 430D, 432D, 438D, 442D
2D9600	MASTER CYLINDER ASSEMBLY	120, 120B, 12E
3D2219	CYLINDER AS	120, 120B, 12E
3D9139	CYLINDER A.	CYLINDER
3K1244	CYLINDER A.	CYLINDER
3K1367	CYLINDER A.	CYLINDER
4K5968	CYLINDER ASSEM	950
5B3217	CYLINDER A.	CYLINDER
5G1297	CYLINDER AS-MASTER	910
5T6520	CYLINDER A	CYLINDER
5T6521	CYLINDER A	CYLINDER
5T6522	CYLINDER G	CYLINDER
5T6617	CYLINDER A	CYLINDER
5T6618	CYLINDER A	CYLINDER
5T7161	CYLINDER GP-WHEEL	120B
5V4003	CYLINDER AS-MASTER	950, 966C, 966R
5V4004	CYLINDER AS	950, 966C, 966R
5V9151	CYLINDER AS-MASTER	920, 930, 930R
9K1591	CYLINDER ASSEM.	518, 528, 528B, 530B, 920, 930, 950
9K8943	CYLINDER GP-AIR OVER HYD	528, 528B, 530B, 920, 930
9R9386	CYLINDER AS	446, 446B, 446D

Master Cylinder Repair Kits & Parts

Part No.	Description	Machine Model
2G0935	KIT (maintenance)	120G
5V9152	KIT (Master Cylinder)	920
2D7747	KIT WHEEL CYLINDER	120B, 140B
7K4434	KIT-CYLINDER	920
8R0957	KIT-CYLINDER	824C, 980C, 980F
1666681	KIT-WHEEL CYLINDER	814B, 815B, 966D, D25C
5D8755	MASTER CYLINDER KIT	120, 120B
6S9592	MASTER CYLINDER REBUILD KIT	910
3D9334	REBUILD KIT	120, 120B, 12E, 14E
5T6532	CYLINDER KIT	CYLINDER
5T6533	CYLINDER KIT	CYLINDER
5T6605	CYLINDER KIT	CYLINDER
5G3047	GASKET	910
3K2097	PISTON	950
4B9000	PISTON	120B, 12E, 140B
8P1186	PISTON	561D, D5B, D6D, D6E, D6E SR, D6F SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
4B8987	PLUG	140B, 14E, 613B, 920, 950
4B8314	CUP	12E
4D0522	CUP	140B, 14E, 910
3K2099	CUP	950
3K6879	CUP	950, 966C, 988
6B2718	CUP	CUP